# Well : Basker 2 Drill, Complete & Clean-up

***NOTE: Other sheets use this START DATE & TIME & POB Information in their setup***

**Starting POB :** 85
**Max POB on rig :** 100
**Start Date & Time :** Sat 6-Aug-05 4:30
**Forecast End Time :** Sat 24-Sep-05 17:00

| Start Time | Description | Target | Actual | Comments |
|---|---|---|---|---|
| 04:30 Sat 06 Aug | Tow rig to Basker-2 from Santos' Henry location | 66.00 hrs | 96.00 hrs | 23.5 hours lost w/ parted tow line |
| 04:30 Wed 10 Aug | Wait on weather to run anchors | 0.00 hrs | 58.50 hrs | |
| 15:00 Fri 12 Aug | Anchor / Position rig | 24.00 hrs | 32.00 hrs | |
| 23:00 Sat 13 Aug | Prepare to spud | 6.00 hrs | 13.00 hrs | |
| 12:00 Sun 14 Aug | Drill 36" hole | 12.00 hrs | 5.50 hrs | |
| 17:30 Sun 14 Aug | Run 30" & PGB & Cement | 12.00 hrs | 18.00 hrs | Also lay down BHAs etc |
| 11:30 Mon 15 Aug | Make up 17.5in BHA, RIH, drill shoe track @ 208m | 7.00 hrs | 6.00 hrs | |
| 17:30 Mon 15 Aug | Drill 17.5in hole to 1006m | 38.00 hrs | 27.00 hrs | 1/2 hr lost w/ mud pump #3 |
| 20:30 Tue 16 Aug | POH, Run and cement 13.375in casing | 34.00 hrs | 24.50 hrs | 7 hrs wiper trip & POOH |
| 21:00 Wed 17 Aug | Run and test BOPs | 30.00 hrs | 35.00 hrs | |
| 08:00 Fri 19 Aug | Velocity survey | 12.00 hrs | 4.00 hrs | Logging Unit Failure |
| 12:00 Fri 19 Aug | Make up 12.25in BHA, RIH, drill shoe track, conduct LOT | 15.00 hrs | 20.00 hrs | |
| 08:00 Sat 20 Aug | Drill 12.25" hole to top of Lakes Entrance at 1758mMD with FEWD | 39.00 hrs | 36.50 hrs | LE at 1755mMD |
| 20:30 Sun 21 Aug | Drill 12.25" hole to top of Latrobe at 2092mMD with FEWD | 22.00 hrs | 12.50 hrs | Latrobe at 2089mMD |
| 09:00 Mon 22 Aug | Drill 12.25" hole to casing point at 2497mMD, POOH | 110.00 hrs | 25.50 hrs | |
| 10:30 Tue 23 Aug | Damaged BOPs - plug well, pull, repair, test & rerun BOPs, remove plug. | 0.00 hrs | 182.00 hrs | |
| 00:30 Wed 31 Aug | M/u 12.25" BHA & RIH | 0.00 hrs | 10.50 hrs | |
| 11:00 Wed 31 Aug | Drill 12.25" hole to csg point at 2962mMD with FEWD (KOP 2578m). | 87.00 hrs | | Problems holding tool face during KO |
| 02:00 Sun 04 Sep | Circ Btms up Wiper trip to shoe. Circ btms up.POOH. Stand back BHA | 10.00 hrs | | |
| 12:00 Sun 04 Sep | Velocity survey | 12.00 hrs | | |
| 00:00 Mon 05 Sep | Condition hole - wiper trip ????? | 0.00 hrs | | |
| 00:00 Mon 05 Sep | Pull w/bushing. | 2.00 hrs | | |
| 02:00 Mon 05 Sep | Rig up, Run & Cmt 9.625" csg. | 30.00 hrs | | |
| 08:00 Tue 06 Sep | Set & test Seal assy. POOH with R/tool | 2.00 hrs | | |
| 10:00 Tue 06 Sep | Test BOP ??? | 0.00 hrs | | **** problem with Start Time formula**** |
| 10:00 Tue 06 Sep | Lay out 12-1/4" BHA. Make up 8.5in BHA, | 5.00 hrs | | |
| 15:00 Tue 06 Sep | RIH, drill shoe track, conduct FIT | 8.00 hrs | | |
| 23:00 Tue 06 Sep | Drill 8.5" hole with GR-Res FEWD tools | 24.00 hrs | | |
| 23:00 Wed 07 Sep | Circulate, POH, stand back out BHA and rig up to log with wireline | 15.00 hrs | | |
| 14:00 Thu 08 Sep | Rig up & run wireline logs (3 runs including 2 MDT and Velocity survey) | 40.00 hrs | | |
| 06:00 Sat 10 Sep | Wiper trip prior to running liner | 20.00 hrs | | |
| 02:00 Sun 11 Sep | Run 7" liner & cement | 36.00 hrs | | |
| 14:00 Mon 12 Sep | Lay out 8-1/2" BHA | 3.00 hrs | | |
| 17:00 Mon 12 Sep | Run “Well Patroller” to clean up well, circulate well clean, spot HEC pill | 27.00 hrs | | Start Cleanup |
| 20:00 Tue 13 Sep | Jet clean BOP and wellhead, POOH. | 9.00 hrs | | |
| 05:00 Wed 14 Sep | Pressure test BOPs & casing/liner | 12.00 hrs | | |
| 17:00 Wed 14 Sep | Rig up Schlumberger electricline run CBL/VDL/GR/CCL Log | 6.00 hrs | | |
| 23:00 Wed 14 Sep | RIH and perforate reqd intervals overbalanced (2 runs, 4 intervals) | 12.00 hrs | | |
| 11:00 Thu 15 Sep | Run gauge ring & junk basket to PBTD, POOH & rig down | 4.00 hrs | | |
| 15:00 Thu 15 Sep | Pull wear bushing | 3.00 hrs | | |
| 18:00 Thu 15 Sep | Rig up tubular handling equipment | 3.00 hrs | | Start Running Completion |
| 21:00 Thu 15 Sep | Run Lead Impression Tool on completion riser (~15 jts/assys) | 3.00 hrs | | |
| 00:00 Fri 16 Sep | Activate LIT to determine TH spaceout, POOH racking back riser. | 3.00 hrs | | |
| 03:00 Fri 16 Sep | Run 3-1/2" Lower Completion String (~20 jts/assys, no C-L) | 3.00 hrs | | |
| 06:00 Fri 16 Sep | Run 3-1/2" IDHC Completion String (~18 jts/assys, 3 x C-L) | 9.00 hrs | | |
| 15:00 Fri 16 Sep | Run 4-1/2" Completion String (~218 jts/assys, 3 x C-L) | 36.00 hrs | | |
| 03:00 Sun 18 Sep | M/u SSSV, run remaining 4-1/2" (~7 jts/assys, 4 x C-L) | 4.00 hrs | | |
| 07:00 Sun 18 Sep | Space out completion, change equip to handle landing string | 3.00 hrs | | |
| 10:00 Sun 18 Sep | M/u & run tubing hanger with 5-1/2" completion riser, space out | 9.00 hrs | | |
| 19:00 Sun 18 Sep | R/u & test Surface Tree & slickline lubricator, land hanger. | 4.00 hrs | | |
| 23:00 Sun 18 Sep | Slickline run & set 2.750" X-Selective Test Tool. | 2.00 hrs | | |
| 01:00 Mon 19 Sep | Pressure up & set packers, test tubing & annulus, shear GLV | 4.00 hrs | | |
| 05:00 Mon 19 Sep | POOH w/ 2.750" X-Selective Test Tool. Close ICV & LV | 1.00 hrs | | |
| 06:00 Mon 19 Sep | Test ICV/LV then test SSSV. Re-open SSSV and bleed off pressures. | 1.00 hrs | | |
| 07:00 Mon 19 Sep | RIH & set 4" plug & prong in tubing hanger, pressure test plug | 3.00 hrs | | |
| 10:00 Mon 19 Sep | Unlatch THRT, POOH & stand back landing string | 6.00 hrs | | |
| 16:00 Mon 19 Sep | Rig down tubular handling equipment, rig up to handle risers | 4.00 hrs | | |
| 20:00 Mon 19 Sep | Unlatch & pull BOPs & LMRP on 18-3/4" Marine Riser | 18.00 hrs | | |
| 14:00 Tue 20 Sep | Run Subsea Tree on completion riser | 18.00 hrs | | |
| 08:00 Wed 21 Sep | R/u & test flowhead & surface lines, land & latch / test tree & riser | 8.00 hrs | | |
| 16:00 Wed 21 Sep | R/u & test slickline lubricator | 3.00 hrs | | |
| 19:00 Wed 21 Sep | Retrieve prong & plug from Tubing Hanger, open SSSV | 4.00 hrs | | |
| 23:00 Wed 21 Sep | RIH, open XD SSD, POOH | 4.00 hrs | | Start Well-test |
| 03:00 Thu 22 Sep | Hold pre-flow meeting, displace tubing to diesel | 4.00 hrs | | |
| 07:00 Thu 22 Sep | RIH, close XD SSD, POOH | 4.00 hrs | | |
| 11:00 Thu 22 Sep | Flow through separator, take fluid samples, shut in Upper Group. | 2.00 hrs | | |
| 13:00 Thu 22 Sep | Open both groups and commingle 30 bbls, then clean up Upper Group | 3.00 hrs | | |
| 16:00 Thu 22 Sep | Open Lower Group and flow through separator, take fluid samples. | 4.00 hrs | | |

| | | |
|---|---|---|
| **20:00 Thu 22 Sep** | Bullhead diesel to below SSSV | 3.00 hrs |
| **23:00 Thu 22 Sep** | Close & leak test SSSV. Close tree valves | 4.00 hrs |
| **03:00 Fri 23 Sep** | Flush riser and surface system with diesel and then seawater | 4.00 hrs |
| **07:00 Fri 23 Sep** | Unlatch & pull completion riser | 6.00 hrs |
| **13:00 Fri 23 Sep** | Install tree debris cap, survey seabed | 4.00 hrs |
| **17:00 Fri 23 Sep** | Pull anchors | 24.00 hrs |
| **17:00 Sat 24 Sep** | Release rig | |