

Well : LONGTOM 3

NOTE: Other sheets use this START DATE & TIME & POB Information in their setup

Starting POB : 88
 Max POB on rig : 100
 Start Date & Time : Mon 10-Jul-06 9:30
 Forecast End Time : Mon 18-Sep-06 9:00

Start Time	Description	Target	Actual
00:30 Sun 13 Aug	Drill out shoe track	2.00 hrs	2.50 hrs
03:00 Sun 13 Aug	Circulate hole clean and perform FIT	3.00 hrs	4.00 hrs
07:00 Sun 13 Aug	Drill 9-1/2" Hole from 2384 - 2900m	33.00 hrs	48.00 hrs
07:00 Tue 15 Aug	Drill 9-1/2" Hole from 2900 - 4150m	135.00 hrs	129.50 hrs
16:30 Sun 20 Aug	Circ hole clean prior to trip at 4080m	4.00 hrs	2.50 hrs
19:00 Sun 20 Aug	POH to replace RST tool and bit	14.00 hrs	18.50 hrs
13:30 Mon 21 Aug	RIH with new bit and RST tool	3.00 hrs	4.00 hrs
17:30 Mon 21 Aug	RIH Test Plug, Test BOPS, POOH Test Plug, Test surface equipment	6.00 hrs	11.50 hrs
05:00 Tue 22 Aug	Load Source in LWD, RIH with new bit and RST tool to TD.	11.00 hrs	13.50 hrs
18:30 Tue 22 Aug	LWD / MWD not communicating with surface, troubleshoot problems while drilling from 4080 - 4090m	0.00 hrs	4.00 hrs
22:30 Tue 22 Aug	POOH to surface to fix communication problem in LWD / MWD	10.50 hrs	
09:00 Wed 23 Aug	Diagnostic checks on LWD / MWD at surface, replace as necessary	3.00 hrs	
12:00 Wed 23 Aug	RIH to TD, filling pipe and circulating as necessary	7.00 hrs	
19:00 Wed 23 Aug	Drill 9-1/2" Hole from 4090 - 4800m	48.00 hrs	
19:00 Fri 25 Aug	Circ hole clean prior to POOH for liner	6.00 hrs	
01:00 Sat 26 Aug	POOH	20.00 hrs	
21:00 Sat 26 Aug	R/U and run Run 7" Liner on 5" DP	34.00 hrs	
07:00 Mon 28 Aug	Set Liner, Displace to brine, Clean surface lines	24.00 hrs	
07:00 Tue 29 Aug	POOH with DP and liner hanger setting tool	6.00 hrs	
13:00 Tue 29 Aug	R/u tbg handling equip, make up 1500m of 3/8" TCP guns and 950m of 4 1/2" TCP guns, arm firing head and install circulating valve	27.00 hrs	
16:00 Wed 30 Aug	RIH TCP guns on 3 1/2" & 5" DP to approx 5000m (top shot at ~2550m), fire guns and circ bottoms up	9.00 hrs	
01:00 Thu 31 Aug	POOH and lay out spent guns	24.00 hrs	
01:00 Fri 01 Sep	RIH and perforate 300 sands overbalanced (1 run), POOH & rig down	6.00 hrs	
07:00 Fri 01 Sep	Run 10 3/4" casing scraper/Well Patroller, scrape across SC-1R packer depth setting depth and POOH.	10.00 hrs	
17:00 Fri 01 Sep	Run Baker SC-1R Packer with FBIV on DP, sting into top of 7" Liner, set packer at approx 2250m, test packer & tailpipe	10.00 hrs	
03:00 Sat 02 Sep	Release setting tool from packer, test casing & POOH drillpipe	7.00 hrs	
10:00 Sat 02 Sep	RIH jetting assy & RBT, clean riser & BOPs, POH	6.00 hrs	
16:00 Sat 02 Sep	RIH & set 10 3/4" Hurricane Pkr & Storm Valve below wellhead, POOH	4.00 hrs	
20:00 Sat 02 Sep	Release and recover BOPs to surface (clean riser & BOPs on deck)	15.00 hrs	
11:00 Sun 03 Sep	Run, land and test SST	24.00 hrs	
11:00 Mon 04 Sep	Run, land and test BOPs	16.00 hrs	
03:00 Tue 05 Sep	RIH & unset 10 3/4" Hurricane Pkr & Storm Valve, POOH w/ same	4.00 hrs	
07:00 Tue 05 Sep	Run Scraper & Well Patroller, jet wellhead with seawater thru SABS, RIH & install plug / debris sub in SC-1R packer	12.00 hrs	
19:00 Tue 05 Sep	Circulate 10 3/4" casing to clean seawater, then spot HEC pill across perf interval and circ well to 10.4 ppg filtered inhibited brine. POOH.	30.00 hrs	
01:00 Thu 07 Sep	Rig up Schlumberger electricline, RIH and perforate 400 sands overbalanced (3 runs), rig down	18.00 hrs	
19:00 Thu 07 Sep	RIH lto spear, scraper & Well Patroller on DP, scrape casing past perfs, retrieve packer plug / debris sub, POOH sideways	14.00 hrs	
09:00 Fri 08 Sep	RIH & retrieve tubing hanger bore protector from SST with DP	2.00 hrs	
11:00 Fri 08 Sep	Rig up tubing handling equipment & 15ft rig balls. Remove diverter.	2.00 hrs	
13:00 Fri 08 Sep	Run IDHC Equip / 2 packers and 5 1/2" completion (~35 jts / assys)	12.00 hrs	
01:00 Sat 09 Sep	Run 7" completion (~145 jts / assys, 2 x C-L Flatpacks)	24.00 hrs	
01:00 Sun 10 Sep	M/u SSSV, run remaining 7" completion (~6 jts / assys, 3 x C-L Flatpacks)	4.00 hrs	
05:00 Sun 10 Sep	Make up and run Tubing Hanger (with Wireline Isolation Sleeve installed) and THRT on 7" landing string (incl SSTT & SSLV)	12.00 hrs	
17:00 Sun 10 Sep	Make up 7" Surface Flow Head and Coflex hoses, land hanger	6.00 hrs	
23:00 Sun 10 Sep	Lock, overpull, close BOPs and test hanger. Test SSTT & SSLV. IWOCs to test CSM. ROV engage gauge penetrator. R/u slickline.	5.00 hrs	
04:00 Mon 11 Sep	R/u slickline, RIH & retrieve Wireline Isolation Sleeve (3.87" ID) from Tbg Hgr, run Short Wireline Protection Sleeve (4.70" ID).	4.00 hrs	
08:00 Mon 11 Sep	R/u slickline, RIH & set 4.313" R Plug below AHC packer, POOH	4.00 hrs	
12:00 Mon 11 Sep	Pressure up tubing string against plug and set bottom (AHC) packer, pressure test tubing, inflow test SSSV.	2.00 hrs	
14:00 Mon 11 Sep	RIH & pull 4.313" R Plug, POOH. Pressure test below AHC packer	3.00 hrs	
17:00 Mon 11 Sep	Open ICV and displace tubing string to diesel.	4.00 hrs	
21:00 Mon 11 Sep	Pressure up on control lines to set top (HF1) packer.	2.00 hrs	
23:00 Mon 11 Sep	Pressure test annulus, top packer and hanger seals. Prepare to flow well, conduct safety meeting.	4.00 hrs	
03:00 Tue 12 Sep	Flow well to clean up Upper Group (400 sands).	3.00 hrs	
06:00 Tue 12 Sep	Flow Upper Group through separator (at 4 different rates), take PVT, bulk & assay samples.	12.00 hrs	
18:00 Tue 12 Sep	SIW at surface and perform build-up test on Upper Group.	12.00 hrs	
06:00 Wed 13 Sep	Close ICV and perform in-flow test to ensure closed OK.	2.00 hrs	

08:00 Wed 13 Sep	Bullhead diesel into well, pressure cycle FBIV open.	5.00 hrs	
13:00 Wed 13 Sep	Have slickline RIH with 4" Selective Shifting Tool to 2250mMDRT to ensure that FBIV is fully open, POOH.	4.00 hrs	
17:00 Wed 13 Sep	Flow well to clean up Lower Group (300/200/100 sands).	9.00 hrs	
02:00 Thu 14 Sep	Flow Lower Group through separator (at 4 different rates), take PVT, bulk & assay samples.	12.00 hrs	
14:00 Thu 14 Sep	SIW at surface and perform build-up test on Lower Group.	12.00 hrs	
02:00 Fri 15 Sep	Close and leak test TRSSSV.	2.00 hrs	
04:00 Fri 15 Sep	Bleed off pressure above and lubricate MEG onto top of TRSSSV.	2.00 hrs	
06:00 Fri 15 Sep	Slickline to retrieve Short Wireline Protection Sleeve from Tbg Hgr.	2.00 hrs	
08:00 Fri 15 Sep	Perform SST Suspension Tests.	9.00 hrs	
17:00 Fri 15 Sep	Run 5.25" tubing hanger plug on slickline, set & test plug.	2.00 hrs	
19:00 Fri 15 Sep	Rig down slickline lubricator & Surface Flow Head, unlatch THRT and pull landing string.	10.00 hrs	
05:00 Sat 16 Sep	Run soft bullnose cleanout string on DP to top of tubing hanger plug and reverse circulate SST & riser clean. POOH.	4.00 hrs	
09:00 Sat 16 Sep	Run Tree Cap on 7" landing string, set same in wellhead and pressure test.	6.00 hrs	
15:00 Sat 16 Sep	Rig up slickline lubricator on 7" landing string (with pump-in sub), run 5.75" tree cap plug on slickline, set & test plug. POOH & r/d slickline.	4.00 hrs	
19:00 Sat 16 Sep	Unlatch and pull BOPs / LMRP / Marine Riser.	12.00 hrs	
07:00 Sun 17 Sep	Run Lightweight Corrosion Cap with ROV, perform seabed survey	2.00 hrs	
09:00 Sun 17 Sep	Pull anchors and release rig	24.00 hrs	